

HYTORC

TOOL MODEL: AVANTI 10 DUAL PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	1840	254	2494	104
1600	1964	272	2663	110
1800	2213	306	3000	124
2000	2462	340	3337	138
2200	2709	375	3673	152
2400	2956	409	4008	165
2600	3204	443	4343	179
2800	3451	477	4678	193
3000	3698	511	5013	207
3200	3945	546	5348	220
3400	4192	580	5683	234
3600	4440	614	6018	248
3800	4687	648	6353	262
4000	4934	682	6689	276
4200	5184	717	7027	290
4400	5433	751	7365	303
4600	5683	786	7704	317
4800	5932	820	8042	331
5000	6182	855	8380	345
5200	6430	889	8717	358
5400	6678	924	9053	372
5600	6927	958	9390	386
5800	7175	992	9726	400
6000	7423	1027	10063	414
6200	7674	1061	10403	427
6400	7925	1096	10744	441
6600	8177	1131	11084	455
6800	8428	1166	11425	468
7000	8679	1200	11765	482
7200	8840	1223	11984	496
7400	9001	1245	12202	510
7600	9163	1267	12421	524
7800	9324	1289	12639	538
8000	9485	1312	12858	552
8200	9827	1359	13322	565
8400	10170	1406	13786	579
8600	10512	1454	14250	593
8800	10855	1501	14714	607
9000	11197	1549	15179	620
9200	11449	1583	15520	634
9400	11701	1618	15861	648
9600	11952	1653	16203	662
9800	12204	1688	16544	676
10000	12456	1723	16885	690